

How to prepare the wall before gluing Basalt and Colline panels.

Instructions for Preparing the Wall Before Installing Basalt and Colline Panels

Before starting work, make sure the walls are properly prepared.

Priming the Walls

Raw walls should be covered with a deep-penetrating primer at least 24 hours before installation. Painted walls must also be primed by applying the primer directly onto the paint.

Dusting and Preparation

The wall must be thoroughly dusted. After preparing the surface for gluing the Basalt or Colline panels, no renovation work should be carried out that could affect the quality of the adhesive bond between the panels and the wall.

Wall Surface

The surface where the panels will be installed must be perfectly flat, free from any depressions or protrusions.

Removing Obstacles

Remove all electrical outlets, switches, etc., leaving only the insulated cables. Take off TV mounts and other installations.

Installing Skirting Boards

If skirting boards are part of the project, they should be installed. If this is not possible, provide a skirting board template and specify its exact dimensions.

Room Cleaning

The room where the work will be carried out should be clean and tidy. There should be no items that could hinder the panel installation, such as desks, furniture, etc., which might obstruct movement.

Installation Teams

During the panel installation, only one installation team should be working in the room at a time.